



INTERNET MÁS RÁPIDO

¿Cómo configuro mi WiFi?

Arris TG862G


1

Conecta tu computadora al modem con el cable de red.



2

Escribe **192.168.0.1** en la barra de direcciones de tu explorador de internet.



3

En seguida debes escribir los siguientes datos para entrar a la configuración.

Login

User Name ?
Password ?

Apply

Da un Click en **Apply**.



INTERNET MÁS RÁPIDO

¿Cómo configuro mi WiFi?

Arris TG862G

4

Ahora podrás ver la siguiente pantalla con las opciones para configurar la red WiFi.

Las opciones deben de verse como en la pantalla siguiente, de lo contrario cámbialas.



Basic Setup

WAN Setup

LAN Setup

Wireless Setup

Firewall

Utilities

BASIC SETUP

BASIC SETUP

System Basic Setup

While your system has many configuration options, the options on this Basic Setup page are those required by most users. Click the tabs to access the other configuration pages to set advanced options. Hover the mouse pointer over the question mark icon next to an option to view a description of that option. For changes to take effect, you must click the Apply button.

Basic Setup

Host Name	ARRISGW	?
Enable Wireless	<input checked="" type="checkbox"/>	?
Wireless Network Name (SSID)	ARRIS-68C2	?
Broadcast Network Name (SSID)	<input checked="" type="checkbox"/>	?
User Name	admin	?
Change Password	<input type="button" value="Change Password"/>	?
Tx Power Level	High	?
Channel	Auto	?
Language	English	?
Security Mode	WPA2-PSK	?

Escribe el nombre de red que deseas.

Security Settings(WPA/WPA2 PSK)

Encryption Algorithm	AES	?
Pre-Shared Key	D37FCDE6F9F86FBC	?
Tx Power Level	High	?
Channel	Auto	?
Language	English	?
Security Mode	WPA2-PSK	?

Escribe la contraseña para la red.

Security Settings(WPA/WPA2 PSK)

Encryption Algorithm	AES	?
Pre-Shared Key	D37FCDE6F9F86FBC	?

WPS Settings

Click en el botón guardar cambios.